




PDF SINGLE USE TEMPERATURE DATA LOGGER QUIK START



No need to tear or cut off the plastic bag from the device.

START

Press and hold the startbutton([see image no.1](#)) for about 3sec. until the **GREEN** LED ([see image no.2](#)) lights to start logging. If the **GREEN** LED ([see image no.2](#)) doesn't light, please don't use this data logger and make sure it's correct to start.

When logging, the **GREEN** LED ([see image no.2](#)) will flash once every 10sec.
Or the **RED** LED ([see image no.3](#)) will flash once every 10sec.

STOP

Press & hold the button ([see image no.1](#)) for approx. 3 sec. to stop logging,
the **RED** LED ([see image no.3](#))

WHEN READING DATA

When inserted into PC's USB port, the data logger will stop also logging.